



PRODUCT DATA SHEET

HEXISGEL

HEXISGEL is a product that facilitates the application of adhesive-coated films (BODYFENCE Range, V202CGI, Cristal, PURE ZONE®, etc.). Compared with soapy water or EASYPOSE, HEXISGEL reduces the films' application time. Its properties allow for the reduction of the initial tack in order to easily fit the films' position. Its composition enables it to be expelled quickly to obtain optimum and fast adhesion to the substrate.

COMPOSITION:

- Water
- Isopropanol: < 5 %.

Contains 1,2-benzisothiazol-3(2H)-one (2634-33-5). May cause allergic reactions.

LIQUID FEATURES:

- Colourless liquid

USER'S INSTRUCTIONS:

- It is recommended to wear protective equipment (gloves, goggles).

The safety data sheet is available upon request.

- Shake the bottle before use.
- Thoroughly spray the HEXISGEL on the application surface and each side of the film.
- Position and adjust the film on the substrate.
- Remove the HEXISGEL and any air bubbles located between the film and the substrate by firmly applying a squeegee from the centre outwards.
- Finalise the application by wiping off HEXISGEL residues with a clean and dry cloth.

STORAGE:

- Keep the HEXISGEL in its original container securely closed, at ambient temperature and protected from direct sunlight.
- Shelf life: 1 year when stored in its unopened original container.

NOTES:

Due to the great variety of substrates and the growing number of new applications, the installer must check the suitability of the medium for each application. All the published information is based on measurements regularly performed in the laboratory. It does not however constitute a binding guarantee. The seller cannot be held liable for indirectly related damages and assumes no liability for claims that are higher than the replacement value of the purchased product. All specifications are subject to potential changes without prior notice. Our specifications are automatically updated on our website www.hexis-graphics.com.